

Assembly Instruction For 3536SWAE

- 1. Attach the glass (C) and bottom cover (B) to the fixture (D).
- 2. Thread the screws (A) from the hole of bottom cover to the hole (E) on the fixture till tight.

