

1. Screw the nipple 1 into the poly pan and attached the arm on the nipple then secure by small finial.
2. Screw the nipple 2 into the coupler then secure by hex nut .
3. Attach the glass and the cap on the nipple 2 the tighten by the finial.

