

## Assembly Instruction For 3532SWAE

- 1. Attach the glass ( C ) and bottom cover ( B ) to the fixture ( D ).
- 2. Thread the screws ( A ) from the hole of bottom cover to the hole ( E ) on the fixture till tight.

